



Instruction Manual



Refrigerator

Model: HS-65L

General

This refrigerator is widely used in places such as hotels ,offices, student dormitories and houses. It is small size, lightweight, low electric consumption and easy use, most suitable for refrigerating and preserving foods such as fruits and beverage.

Instructions for Installation

1. Do not tilt the refrigerator more than 45⁰ from upright during moving. Do not apply force on any part such as condenser and door to prevent the refrigerator from deforming as this can influence its performance.
2. Allow the refrigerator enough space to operate well.
3. Do not install it in areas of high temperature or humidity to avoid damage.

Cautions for Safety

1. Before the refrigerator is plugged in, ensure that the local electric voltage (e.g. 240V) is the same as the rated voltage. The power plug should have its independent socket as adapter may cause the socket to overheat.
2. Do not store inflammable materials such as ether, benzine, LP gas and glue etc. in the refrigerator.
3. Do not splash water on the refrigerator as it may cause malfunction or electric shock.

Instructions for Use

1. When operating the refrigerator for the first time, run it without loading any food until it automatically stops at the desired temperature. Usually it takes 2 or 3 hours. Then, set the thermostatic dial at the setting desired and put food in the refrigerator.

2. The temperature of the refrigerator can be adjusted by turning the thermostatic dial. A medium setting of the thermostatic dial is the most suitable for general operation.
3. Defrost the freezing compartment whenever the layer of frost on the surface of the evaporator reaches 3 or 4 mm. When defrosting, remove all food and set the thermostat at "OFF" position. Put the drip tray under the evaporator to collect melted water. After the frost has melted, discard the melted water and dry up the interior of refrigerator. The refrigerator can then be restarted by turning its thermostat to the desired setting.

Cautions for Use

1. The more food is put in or the more and the longer the door is opened, the more electric it consumes, which may eventually lead to malfunction.
2. Better not to place objects which are too heavy, pointed or corrosive on table board.
3. Re-plugging in the power plug at the interval of over ten minutes.
4. Do not store bottled drinks in the freezer as they may break and damage the refrigerator.
5. Open the door as little as possible during power-cut.
6. When defrosting, never use any sharp or metallic objects to remove the frost on the surface of the evaporator as it will damage the evaporator.
7. Do not touch any food or container in the freezing compartment with your wet hands to prevent frostbit.

Maintenance

1. While cleaning the refrigerator, pull out the electric power plug. Wipe the refrigerator carefully with a piece of cloth soaked with natural cleanser before wiping it with clean water. Abrasive cleaning powder, alkali cleansers, chemical cloth, thinner, alcohol, acid petroleum product and hot water are not suitable for cleaning the refrigerator as they may cause permanent damage to the painting cover and plastic.
2. Clean the door gasket whenever it is dirty.
3. If the refrigerator is out of use for a long time, pull out the plug, clean and dry the freezing compartment then close the door tightly.

The following cases are not malfunction

1. Sound of flowing water:
The sound of flowing water can be heard under normal operation.
2. Outside condensation:
Outside condensation is normal in areas of high humidity. You may wipe off the condensation with a cloth.
3. It takes some time for the temperature of the freezer and refrigerator compartment to become cold after the refrigerator starts to operate. If the environmental temperature is higher, it will take a longer time to cool the compartments.
4. The surface of the compressor becomes hot:
The surface of the compressor may become hot under normal operation. Do not touch it with your hands.

Troubleshooting

If any case of malfunction, please inspect and rectify it according to the checklist shown in the following table.

case	Inspection
Not refrigerating	Is there no electric current? Is the voltage normal or not? Has the socket fused? Is the plug inserted into the socket correctly?
Not efficient	Is the thermostatic dial set to the correct position? Is there sufficient clearance space around the refrigerator? Has the door been opened too frequently or for too long? Is the refrigerator exposed to direct sunlight or placed near heating devices? Are there too much food inside? Are the food too hot? Is the room temperature too high?
Food frozen in the refrigerator compartment	Is the thermostatic dial set to the correct position? Have the food been put too close to each other?

Noises	Is the refrigerator placed on a leveled surface? Has the refrigerator been struck by some other objects?
Compressor does not stop automatically	Are the food stored too much at one setting? Are the doors opened too frequently or for too long?

If the above methods are not effective, please contact your local Midea Service Centre for assistance.

DANGER or WARNING:

1. Risk of child entrapment. Before you throw away your old refrigerator or freezer:

-Take off the door.

-Leave the shelves in place so that children may not easily climb inside.”

2. Do not use extension cords.

For household refrigerating appliances

Try not to open the door too often, especially when the weather is wet and hot. Once you open the door, mind to close it as soon as possible.

Every now and then check if the appliance is sufficiently ventilated (adequate air circulation behind the appliance).

For household refrigerating appliances, in normal temperature conditions, please arrange the thermostat at the middle setting.

Before loading the appliance with packages of fresh foods, make sure they are cooled to ambient temperature.

Ice and frost layer increase energy consumption, so do clean the appliance as soon as the layer is 3-5 mm thick.

If it is the outer condenser, the rear wall should be always clean free of dust or any impurities.

Always consider instructions stated in sections Positioning and Energy Saving Tips, otherwise the energy consumption is substantially higher.

WARNING

- 1) The appliance has to be unplugged after use and before carrying out user maintenance on the appliance.
- 2) This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 3) Children should be supervised to ensure that they do not play with the appliance.
- 4) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 5) Please abandon the refrigerator according to local regulators for it use flammable blowing gas.