

Size: 19.685" x 17.5"

Please Read and Save this Use and Care Book.

IMPORTANT SAFEGUARDS

When using your iron, basic safety precautions should always be followed, including the following:

- **READ ALL INSTRUCTIONS BEFORE USING.**
- Only use iron for its intended use.
- To avoid risk of electric shock, do not immerse the iron in water or other liquids.
- Always turn iron off before plugging or unplugging from the electrical outlet. Never pull on the cord to disconnect the iron from the electrical outlet; instead, grasp the plug and pull on the plug to disconnect the iron.
- Do not let the cord touch hot surfaces. Let the iron cool completely before putting the iron away. Coil the cord loosely around the iron when storing.
- Always disconnect the iron from the electrical outlet before filling the iron with water, emptying the water from the iron, and when the iron is not in use.
- Do not operate the iron with a damaged cord or in the event the iron has been dropped or damaged. To avoid the risk of electric shock, do not disassemble the iron. Take it to a qualified serviceman for examination and repair. Incorrect assembly might result in a risk of electric shock when the iron is used after reassembly.
- Close supervision is necessary for any appliance used by or near children. Do not leave the iron unattended while the iron is connected or on an ironing board.
- Burns can occur from touching hot metal parts, hot water or steam. Use caution when you turn a steam iron upside down— there might be hot water in the reservoir.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The iron must be used and rested on a stable surface.
 - When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
 - The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.

- allow it to cool off.
- 2. Empty the water by holding the iron over a sink with the tip pointing down. Water will empty out of water-fill opening.

Care and Cleaning

This product contains no user serviceable parts. Refer service to qualified service personnel.

CLEANING OUTSIDE SURFACES

1. Make sure iron is unplugged and has cooled completely. Wipe the soleplate and outer surfaces with a soft cloth dampened with water. Never use abrasives, heavy-duty cleansers, vinegar or scouring pads that may scratch or discolor the iron.
2. After cleaning, steam iron over an old cloth to remove any residue from the steam vents.

STORING YOUR IRON

1. Check that the selector is set to ☁ .
2. Unplug the iron. Stand the iron on its heel rest and allow it to cool off.
3. Store vertically on its heel rest to prevent water leaking from the soleplate, or you can empty the water tank.

SPECIAL INSTRUCTIONS

- To avoid a circuit overload, do not operate an iron on the same circuit with another high wattage appliance.
- If an extension cord is absolutely necessary, a cord with an ampere rating equal to or greater than the maximum rating of the iron should be used. A cord rated for less amperage can result in a risk of fire or electric shock due to overheating. Care shall be taken to arrange the cord so that it cannot be pulled or be tripped over.

SAVE THESE INSTRUCTIONS.

This product is for household use only.

POLARIZED PLUG (120V models only)


This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

TAMPER-RESISTANT SCREW

Warning: This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel.

Note: If the power supply cord is damaged, it should be replaced by qualified personnel; in Latin America, by an authorized service center.

Product may vary slightly from what is illustrated.



How to Use

This appliance is for household use only.

GETTING STARTED

Remove any labels, stickers or tags attached to the body or soleplate of the iron. **Note:** Use ordinary tap water for ironing. Do not use water processed through a home softening system.

Important: For optimum performance, let the iron stand for 90 seconds before beginning to iron.

TO FILL THE WATER TANK

1. Tilt the iron and using a clean measuring cup, pour water into opening until the water reaches the MAX level mark on the water tank. Do not overfill. Refill as needed.
2. Plug in the iron. Temperature-ready light glows when iron has reached set temperature setting.

Tip: If unsure of a garment's fiber, test a small area (on an inside seam or hem) before ironing.

FOR STEAM IRONING

1. Move the dry/steam selector to the desired steam level.
2. Turn the fabric-select dial to appropriate setting (between 4 and 6) for your fabric. See fabric guide on the heel rest and read garment's label to help you determine fabric type. The temperature-ready light glows until it reaches the appropriate temperature. It then cycles on and off during ironing.
3. When finished ironing, turn the fabric-select dial to lowest heat setting, move the selector to ☁ and unplug the iron. Stand the iron on its heel rest and allow it to cool off.

Important: Always stand the iron on its heel rest when powered on but not in use.

FOR DRY IRONING

1. Make sure dry/steam selector is set to ☁ . **Note:** It is recommended that you empty the water (see "Emptying Water Tank After Ironing").
2. Turn the fabric-select dial to the appropriate setting for your fabric. See fabric guide on the heel rest and read garment's label to help you determine fabric type. The temperature-ready light glows until it reaches the appropriate temperature. It then cycles on and off during ironing.
3. For optimum performance, let the iron stand for 90 seconds before beginning to iron.
4. When finished ironing, turn the fabric-select dial to lowest heat setting, move the selector to ☁ and unplug the iron. Stand the iron on its heel rest and allow it to cool off.

Important: Always stand the iron on its heel rest when powered on but not in use.

SPRAY

You can use spray at any setting. Check that the water tank is filled with water. Press the ☂ button. If spray is weak, pump the button a few times.

EMPTYING WATER TANK AFTER IRONING

Note: It is not necessary to empty the water after each use.

1. Turn the fabric-select dial to ☁. Unplug the iron. Stand the iron on its heel rest and

Póliza de Garantía

(Válida sólo para México)

Duración

SPECTRUM BRANDS DE MÉXICO, SA de C.V. garantiza este producto por 2 años a partir de la fecha original de compra.

¿Qué cubre esta garantía?

Esta Garantía cubre cualquier defecto que presenten las piezas, componentes y la mano de obra contenidas en este producto.

Requisitos para hacer válida la garantía

Para reclamar su Garantía deberá presentar al Centro de Servicio Autorizado la póliza sellada por el establecimiento en donde adquirió el producto. Si no la tiene, podrá presentar el comprobante de compra original.

¿Donde hago válida la garantía?

Llame sin costo al teléfono 01 800 714 2503, para ubicar el Centro de Servicio Autorizado más cercano a su domicilio en donde usted podrá encontrar partes, componentes, consumibles y accesorios.

Procedimiento para hacer válida la garantía

Acuda al Centro de Servicio Autorizado con el producto con la póliza de Garantía sellada o el comprobante de compra original, ahí se reemplazará cualquier pieza o componente defectuoso sin cargo alguno para el usuario final. Esta Garantía incluye los gastos de transportación que se deriven de su cumplimiento.

Excepciones

Esta Garantía no será válida cuando el producto:

- A) Se hubiese utilizado en condiciones distintas a las normales.
- B) No hubiese sido operado de acuerdo con el instructivo de uso que le acompaña.
- C) Cuando el producto hubiese sido alterado o reparado por personas no autorizadas por SPECTRUM BRANDS DE MÉXICO, SA de C.V. .

Nota: Usted podra encontrar partes, componentes, consumibles y accesorios en los centros de servicios autorizados. Esta garantía incluyen los gastos de transportación que se deriven de sus cumplimiento dentro de sus red de servicio.

Por favor llame al número correspondiente que aparece en la lista a continuación para solicitar que se haga efectiva la garantía y donde Ud. puede solicitar servicio, reparaciones o partes en el país donde el producto fué comprado.	
Argentina Atención al consumidor 0800 444 7296 Horario de atención: Lunes a viernes de 9 a 13 hs y de 14.30 a 17 hs. Mail: servicios@rayovac.com.ar Humboldt 2495 piso 3 San José, Argentina	Honduras Serviteca San Pedro Sula, B Los Andes, 2 calle -entre 11-12 Avenida Honduras Tel. (504) 2550-1074 México Artículo 123 # 95 Local 109 y 112 Col. Centro, Cuauhtemoc, México, D.F. Tel. 01 800 714 2503
Chile SERVICIO DE MAQUINAS Y HERRAMIENTAS LTDA. Portugal N° 644 Santiago – Chile Fonos: 02-6355208 / 02-6341169 Email: servicio@spectrumbrands.cl Call center: 800-171-051	Nicaragua LRM ELECTRONICA Managua - Sinsa Altamira 1.5 kilómetros al norte Nicaragua Tel. (505) 2270-2684
Colombia Rayovac Varta S.A Carrera 17 Número 89-40 Línea gratuita nacional 018000510012	Panamá Supermarcas Centro comercial El dorado, Plaza Dorado, Local 2. Panama Tel. (507) 392-6231
Costa Rica Aplicaciones Electromecanicas Calle 22 y 24 en Avenida 3 BLV de la torre Mercedes Benz 200 mts norte y 50 mts este San José, Costa Rica Tel. (506) 2257-5716	Perú Servicio Central Fast Service Jesús P. Piñero #1013 Puerto Nuevo, S.J PR 00920 Tel.: (787) 782-6175
Ecuador Servicio Master Dirección: Capitán Rafael Ramos OE 1-85 y Galo plaza Iasso. Tel. (593) 2281-3882 / 2240-9870	República Dominicana Prolongación Av. Rómulo Betancourt Zona Industrial de Herrera Santo Domingo, República Dominicana Tel.: (809) 530-5409
El Salvador Sedeblack Calle San Antonio Abad, Colonia Lisboa No 2936 San Salvador, Depto. de San Salvador Tel. (503) 2284-8374	Venezuela Inversiones BDR CA Av. Casanova C.C. City Market Nivel Plaza Local 153 Diagonal Hotel Melia, Caracas Tel. (582) 324-0969
Guatemala Kinal 17 avenida 26-75, zona 11 Centro comercial Novicentro, Local 37 - Ciudad Guatemala Tel. (502)-2476-7367	